

Muttersprenger der Reihe Hi-Force NS

Austauschanleitung für Muttersprengerklingen

Nut splitter blades can be replaced by firstly removing the tapped plug in the side of the Nut splitter body. This provides access to the blade retaining screw, which can then be loosened, and the blade pulled from the end of the piston. Care should be taken when carrying out this operation to prevent injury from the blade particularly when fitting a replacement.

Refitting is the reverse procedure taking care to ensure the blade retaining screw is correctly tightened. This operation should be carried out with the nut splitter disconnected from the pump.

Muttersprengerklingen können ausgetauscht werden indem man zuerst den angezapften Stecker in der Seite des Muttersprengers entfernt. Dies liefert Zugang zur Klinge, die durch eine Schraube befestigt ist, die dann gelockert werden kann um die Klinge am Ende aus dem Kolben zu ziehen.

Beim Einsetzen der neuen Klinge ist in umgekehrter Reihenfolge zu verfahren. Es ist sicherzustellen, dass die Schraube die die Klinge hält richtig festgezogen wird.

Beim Klingenwechsel sollte besonders vorsichtig und sorgfältig vorgegangen werden, um Verletzungen zu vermeiden. Die gesamte Arbeit darf nur durchgeführt werden wenn der Muttersprenger von der Pumpe getrennt wurde.

